

# WHY THE BEE COZY?

IN THE LAST FEW YEARS WINTER HIVE LOSSES HAVE REACHED ABOVE THE 50% RANGE IN MANY NORTH AMERICAN REGIONS. BEE COZY WRAPS HAVE BEEN USED SUCCESSFULLY DURING THE LONG CANADIAN WINTERS FOR OVER 25 YEARS.

## PROTECTIVE

THE BEE COZY SUPPORTS THE BEES THROUGH THE COLD WINTERS & HELPS MAINTAIN AMBIENT TEMPERATURES.



## EFFICIENT

SAVE VALUABLE TIME! THE BEE COZY IS READY-TO-USE WITH A 'SLIP ON, SLIP OFF' METHOD!



## AFFORDABLE

THE BEE COZY IS REUSABLE - REDUCING ANNUAL WINTERING COSTS.



## SUSTAINABLE

BUILT FROM ENVIRONMENTALLY FRIENDLY MATERIALS.



# WHERE TO PURCHASE?

Bee Cozy Winter Hive Wraps are sold through many distributors across Canada and United States. For a full list of our distributors please visit our website [www.NODGLOBAL.com](http://www.NODGLOBAL.com) or call **866 483 2929**.

To inquire about becoming a reseller call **866 483 2929**.

### Shipping FOB:

Frankford, Ontario | Detroit, Michigan

## CUSTOMER SUPPORT

+1 866 483 2929

+1 613 398 8422

[info@nodglobal.com](mailto:info@nodglobal.com)

To learn more visit:

[www.NODGLOBAL.com](http://www.NODGLOBAL.com)



**Bee Cozy**  
WINTER HIVE WRAPS



*Healthy Bees. Healthy Planet.*



# WHY INSULATE?

MAXIMIZE YOUR HONEY CROP BY WINTERIZING YOUR COLONIES.




HEALTHY, OVERWINTERED COLONIES PRODUCE UP TO 2X THE AMOUNT OF HONEY COMPARED TO OTHER COLONIES AND START OFF STRONGER IN THE SPRING.


DURING WINTER, BEES ROTATE FROM THE CENTER TO THE OUTER EDGE OF THE CLUSTER.

WRAPPING PROVIDES THE INSULATING LAYER BEES NEED TO REDUCE THE OVERALL RATE OF HEAT LOSS FROM THE HIVE WHILE ALSO SUPPLYING A WINDBREAK FOR BREEZY LOCATIONS.

SEAM IN FRONT PROVIDES "CHIMNEY" FOR BEES TO ACCESS FRESH AIR. TOP AND BOTTOM ENTRANCES ARE NEEDED TO PROVIDE SUFFICIENT VENTILATION.




## 1 CREATE A BOTTOM OPENING




PLACE A 2" NAIL ABOVE ENTRANCE REDUCER TO LIFT COZY UP, CREATING A BOTTOM ENTRANCE.

## 2 TIP COLONIES FORWARD




TIP COLONIES FORWARD SLIGHTLY WITH SHIMS TO ALLOW MOISTURE TO RUN AWAY FROM ENTRANCE.

## 3 ROLL AIR OUT OF WRAP




ROLL EXCESS AIR OUT OF COZY SO IT CAN SLIDE ON COLONY MORE EASILY AND HELPS PREVENT TEARS.

## 4 PLACE WRAP SEAM TO FRONT




KEEP SEAM TO THE FRONT OF THE COLONY, THIS CREATES A TUNNEL FOR THE BEES TO MOVE AROUND.

## 5 PLACE INNER COVER PAD



PLACE INNER COVER PAD INSIDE A DEEP INNER COVER. PAD CAN ALSO WORK WITH A SHALLOW SUPER.

## 6 UNWRAP AND STORE



COMPRESS AND SLIDE INTO BARREL BAGS. STORE BAGS IN A DRY LOCATION.